

# WH-1000XM5

YY2954

## SERVICE MANUAL

### for PROFESSIONAL REPAIRERS

**Conditions of Use:**

- (1) Please use this information only for the purpose of performing repair and recycling Sony products. Using this information for any purpose other than the purpose described foregoing is forbidden.
- (2) Do not copy, replicate, reproduce, alter, translate, transmit, sell, lease, or distribute this information in whole or in part without the prior written permission of the author.

**Revision of Information:**

This information may be changed or updated at any time without any prior notice. Please confirm that this information is up-to-date before using it.

**CAUTION**

Danger of explosion if battery is incorrectly replaced.  
Replace only with the same or equivalent type.

**Note:**

Be sure to keep your PC used for service and checking of this unit always updated with the latest version of your anti-virus software.  
In case a virus affected unit was found during service, contact your Service Headquarters.

# WH-1000XM5

## YY2954

# SERVICE MANUAL

## for PROFESSIONAL REPAIRERS

*French Model*



- This unit has two types of names for model name (WH-1000XM5), and model (YY2954).

### SPECIFICATIONS

Headset	Communication specification
<p><b>Power source:</b> DC 5 V / 1.6 A (Using a commercially available USB Normal AC adaptor) DC 5 V / 1.6 A and 9 V / 2.3 A (Using a commercially available USB Power Delivery AC adaptor) or use built-in lithium-ion batteries (Product Operation Power: DC 3.8 V)</p> <p><b>Operating temperature:</b> 0 °C to 40 °C</p> <p><b>Power consumption:</b> Low power mode: 0.5 W or less * This unit enters Low power mode immediately after charging is completed when connected to the AC adaptor.</p> <p><b>Mass:</b> Approx. 250 g</p> <p><b>Impedance:</b> 48 Ω (1 kHz) (when connecting via the headphone cable with the unit turned on) 16 Ω (1 kHz) (when connecting via the headphone cable with the unit turned off)</p> <p><b>Sensitivity:</b> 102 dB/mW (when connecting via the headphone cable with the unit turned on) 100 dB/mW (when connecting via the headphone cable with the unit turned off)</p> <p><b>Frequency response:</b> 4 Hz - 40 000 Hz (JEITA) (when connecting via the headphone cable with the unit turned on)</p> <p><b>Included items:</b> Wireless Noise Cancelling Stereo Headset (1) USB Type-C® cable (USB-A to USB-C®) (approx. 20 cm) (1) Headphone cable (approx. 1.2 m) (1) Carrying case (1)</p>	<p><b>Communication system:</b> Bluetooth Specification version 5.2</p> <p><b>Output:</b> Bluetooth Specification Power: Class 1</p> <p><b>Frequency band:</b> 2.4 GHz band (2.4000 GHz - 2.4835 GHz)</p> <p><b>Operating frequency:</b> Bluetooth: 2 400 MHz - 2 483.5 MHz</p> <p><b>Maximum output power:</b> Bluetooth: &lt; 7 dBm</p> <p>Design and specifications are subject to change without notice.</p> <p><b>System requirements for battery charge using USB</b></p> <p><b>USB AC adaptor</b> A commercially available USB AC adaptor capable of supplying an output current of 1.5 A or more</p> <p><b>Commercially available AC adaptor compatible with USB PD (USB Power Delivery)</b> It is recommended that you use the adaptor whose output is 5 V / 2 A or 9 V / 3 A. We do not guarantee the operations with all the devices compatible with USB PD.</p> <p><b>Compatible iPhone/iPod models</b></p> <p>iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone 5s, iPod touch (7th generation), iPod touch (6th generation) (As of February 2022)</p>

### Trademarks

- Apple, iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
- The LDAC name and logo are trademarks of Sony Corporation.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, ™ and ® marks are not specified.

# WIRELESS NOISE CANCELING STEREO HEADSET

**WH-100XM5****TABLE OF CONTENTS**

<b>1. SERVICING NOTES</b> .....	4
<b>2. DISASSEMBLY</b>	
2-1. Disassembly Flow .....	6
2-2. Earpad .....	7
2-3. How to Install the Earpad .....	8
2-4. Screen.....	9
2-5. How to Install the Screen.....	9
2-6. Battery Cable Connector-1 (R-ch).....	10
2-7. Battery Cable Connector-2, Housing Rear R Sub Assy (R-ch) .....	11
2-8. SUB R Board-1 (R-ch) .....	12
2-9. SUB R Board-2 (R-ch) .....	13
2-10. SUB R Board-3 (R-ch) .....	14
2-11. SUB R Board-4 (R-ch) .....	15
2-12. USB R Board-1 (R-ch) .....	16
2-13. USB R Board-2 (R-ch) .....	17
2-14. Housing Rear L Sub Assy (L-ch).....	18
2-15. JACK L Board-1 (L-ch).....	19
2-16. JACK L Board-2 (L-ch).....	20
2-17. Headband Assy-1 (Relay Cable: L-ch) .....	21
2-18. Headband Assy-2 (Relay Cable: R-ch).....	22
2-19. Headband Assy-3 (Connector: R-ch).....	23
2-20. Headband Assy-4 (Screw and MMD R Wire: R-ch) .....	24
2-21. Headband Assy-5 (SUB R Board: R-ch) .....	25
2-22. Headband Assy-6 (Cushion Housing: L/R-ch).....	26
2-23. Headband Assy-7 .....	27
<b>3. EXPLODED VIEWS</b>	
3-1. Earpad Section .....	28
3-2. Housing Section (R-ch) .....	29
3-3. SUB R Board Section .....	30
3-4. Housing Section (L-ch).....	31
3-5. JACK L Board, USB R Board, Headband Assy Section ...	32
<b>4. ACCESSORIES</b> .....	33

**WH-1000XM5****SECTION 1  
SERVICING NOTES**

The **SERVICING NOTES** contains important information for servicing. Be sure to read this section before repairing the unit.

**UNLEADED SOLDER**

Boards requiring use of unleaded solder are printed with the lead-free mark (LF) indicating the solder contains no lead.

**(Caution:** Some printed circuit boards may not come printed with the lead free mark due to their particular size)

**LF : LEAD FREE MARK**

Unleaded solder has the following characteristics.

- Unleaded solder melts at a temperature about 40 °C higher than ordinary solder.  
Ordinary soldering irons can be used but the iron tip has to be applied to the solder joint for a slightly longer time.  
Soldering irons using a temperature regulator should be set to about 350 °C.  
**Caution:** The printed pattern (copper foil) may peel away if the heated tip is applied for too long, so be careful!
- Strong viscosity  
Unleaded solder is more viscous (sticky, less prone to flow) than ordinary solder so use caution not to let solder bridges occur such as on IC pins, etc.
- Usable with ordinary solder  
It is best to use only unleaded solder but unleaded solder may also be added to ordinary solder.

**ABOUT THE LITHIUM-ION RECHARGEABLE BATTERY**

The lithium-ion rechargeable battery built into this unit cannot be replaced with a new battery.

**ABOUT REUSE OF THE LITHIUM-ION RECHARGEABLE BATTERY**

When removing the lithium-ion rechargeable battery from adhesive sheet, the lithium-ion rechargeable battery cannot be reused.

**ABOUT MODEL NAME**

This unit has a model in addition to the model name.

There is no model name on the headset body.

Only the model is written on the model number label.


Model name : WH-1000XM5

Model : YY2954

**CHECKING METHOD OF SERIAL NUMBER**

When checking the serial number, turn over the cushion part of the earpad on the L-ch side, and refer to the label affixed to the inner wall of the plate front.

**Note:** When the headphone assy is replaced with a new part, the serial number will change.

**COLOR VARIATIONS**



(B) Black, (S) Platinum Silver, (L) Midnight Blue, (P) Smoky Pink

**MODEL IDENTIFICATION**

To identify the destination or check the model name, model, refer to the model number label inside the cushion of the earpad on the L-ch side.

**Note 1:** The contents of model number label might be changed in the mid-way of production.

**Note 2:** The model name (WH-1000XM5) is not indicated on the model number label or the print on the main unit.



**Note 3:** This model number label indicates that it is WH-1000XM5/YY2954 for France (European area). If the model number label is other than this, it is WH-1000XM5/YY2954 with a destination other than France (European area).

**BLUETOOTH CONNECTION CHECK**

To check the connection with the BLUETOOTH device, refer to the help guide with WH-1000XM5.

WH-1000XM5 does not have the NFC function.

**Note:** After completing the BLUETOOTH connection checking work, be sure to refer to "INITIALIZATION METHOD" on page 5 to perform initialization and delete the device pairing information.

## WH-1000XM5

### RESETTING METHOD

If the headset does not turn on the power, or if it does not work properly, such as when it is turned on the power but you cannot operate it, reset it according to the following procedure.


**Note 1:** Even if this operation is performed, the device registration information and other settings are retained.

#### Resetting procedure:

1. Connect the USB Type-C cable that came with the headset to the booted PC or sold separately USB AC adaptor to charge the headset, and check that the charging indicator light up orange.
2. Press the [⏻] button and [NC/AMB] button simultaneously. (The charging indicator light off and then light up again)
3. The headset reset.

**Note 2:** When charge the headset after performing a reset, disconnect the USB Type-C cable from the headset and reconnect it.

#### Connection:



### INITIALIZATION METHOD


After completing the repairing and replacing, be sure to initialize the headset according to the following procedure.

**Note 1:** When initialization is performed, all device pairing information is deleted and settings return to factory defaults.

#### Initialization procedure:


1. Check that the USB Type-C cable is not connected to the headset, press and hold the [⏻] button until the indicator (blue) light off (about 2 seconds), and turn off the power.

**Note 2:** If already power is turned off, check the USB Type-C cable is not connected, perform the work from step 2.



2. Press and hold the [⏻] button and [NC/AMB] button simultaneously for about 7 seconds, the indicator (blue) flashing 4 times to complete the initialization, and the settings automatically return to the factory default.

**Note 3:** After performing initialization, delete the pairing of headset from the BLUETOOTH device such as a smartphone, and then pairing the device again.




## SECTION 2 DISASSEMBLY

- This set can be disassembled in the order shown below.

### 2-1. DISASSEMBLY FLOW

**Note 1:** The lithium-ion rechargeable battery is built in on the R-ch side.  
When disassembling this unit, disassemble the R-ch side first, disconnect the battery connector from the SUB R board, disconnect the connection between the battery and the board, and then perform other necessary disassembly work.  
Be careful of short circuits during the disassembly process until the battery connector is removed.




# WH-1000XM5


**Note:** Follow the disassembly procedure in the numerical order given.

## 2-2. EARPAD

- Note 1:** The left and right earpads can be removed using the same procedure. This explanation uses illustrations from the left channel side.
- Note 2:** See page 8 for how to install the earpad.
- Note 3:** The model number label is displayed inside the left earpad. When checking the destination, refer to "MODEL IDENTIFICATION" on page 4.



**• How to remove the earpad**  
 Refer to the figure below, hold the plate earpad (hard plastic part internal of the earpad) by hand, pull it inside until sound that claw of the earpad remove from the housing block is heard, and remove the total of six claws in order.



**NG**

**Note 4:** Do not hold and pull the cushion portion of the earpad. Doing so will damage the earpad.

The diagram shows the correct way to hold the earpad, avoiding the cushion portion.

**• How to identify the L-ch/R-ch earpads**  
 There is a model number label inside the earpad on the L-ch. It is also possible to identify the L-ch and R-ch earpads by the presence or absence of model number label.

(L-ch) - Inner view - top side (R-ch) - Inner view - top side

(L-ch) - Inner view - lower side (R-ch) - Inner view - lower side

"L" is engraved "R" is engraved

This section provides instructions on how to identify the L-ch and R-ch earpads. It shows the inner view of both sides (top and lower) for both L-ch and R-ch earpads. The L-ch earpad has "L" engraved on it, and the R-ch earpad has "R" engraved on it.


**WH-1000XM5****2-3. HOW TO INSTALL THE EARPAD**

**Note 1:** The left and right earpads can be installed using the same procedure.  
This explanation uses illustrations from the left channel side.


**Note 2:** The model number label is displayed inside the left earpad.  
When checking the destination, refer to “MODEL IDENTIFICATION”  
on page 4.

Attach in order from ① to ⑥.


① Align the two ribs and two holes.




② Press the earpad to the housing block until sound that six claws of the earpad firmly catch in the hooks of the housing block is heard.




③ Insert a few fingers into the inner side of the earpad (lower side), and lift the earpad to the outer side to remove wrinkles.




④ Insert a few fingers into the inner side of the earpad (left side), and lift the earpad to the outer side to remove wrinkles.



⑤ Insert a few fingers into the inner side of the earpad (top side), and lift the earpad to the outer side to remove wrinkles.



⑥ Insert a few fingers into the inner side of the earpad (right side), and lift the earpad to the outer side to remove wrinkles.



**Note 3:** Before performing steps ③ to ⑥, make sure that the claws of the earpad are firmly locked to the housing block.


**Note 4:** In steps ③ to ⑥, wrinkles on the earpad resulting from customer use cannot be removed.



# WH-1000XM5

## 2-4. SCREEN


**Note:** The left and right screens can be removed using the same procedure.  
This explanation uses illustrations from the left channel side.




## 2-5. HOW TO INSTALL THE SCREEN

• **Checking before installing the screen**  
< Fig. A >


Before installing the screen, be sure to check that the cover FB MIC and bushing FB MIC are completely installed into the plate front.




Attach in order from ① to ④.




② Align the ribs.



③ Press.




④ Press firmly from the top.



**NG**



The screen is not completely inserted into the plate front.



# WH-1000XM5




## 2-6. BATTERY CABLE CONNECTOR-1 (R-ch)

• Continued on 2-7 (page 11).




### • Checking before installing the housing rear R sub assy < Fig. B >

Before installing the housing rear R sub assy, be sure to check that the flexible flat cable (20 core) and R 3 MIC module are correctly installed.




### • Checking after installing the housing rear R sub assy



### • Housing rear R sub assy installing setting < Fig. C >

When installing the housing rear R sub assy, be sure to install while bending along the fold of TPAD R flexible board.



# WH-1000XM5

## 2-7. BATTERY CABLE CONNECTOR-2, HOUSING REAR R SUB ASSY (R-ch)

- R-ch -

**Note:** When peeling off the adhesive cable battery, be careful not to damage the coating of lithium-ion rechargeable battery.

**• Battery cable setting**  
Attach in order from ① to ④.

① Arrange the battery cable between the housing middle and R 1 MIC module.

② Press the battery cable to make it L-shaped.

③ Paste the adhesive cable battery from the inside of SUB R board.

④ Paste the adhesive cable battery while pressing it against the battery cable.

**• How to install the TPAD R flexible board**  
When installing the TPAD R flexible board, ensure that the white line is parallel to the connector after insertion.

**OK**

Insert straight into the interior.

TPAD R flexible board  
white line  
connector

**NG**


Insert at a slant.

TPAD R flexible board  
white line  
connector

# WH-1000XM5

## 2-8. SUB R BOARD-1 (R-ch)

• Continued on 2-9 (page 13).



**• Relay cable setting**  
Attach in order from ① to ⑥.

① Arrange the wire [blue] of relay cable on the "B" mark side.

**< Fig. D >**

③ Insert the connector vertically. (The [blue] wire is "B" mark side)


④ Arrange the relay cable inside the rib.

⑤ Insert the relay cable inside the hook.

⑥ Check that the relay cable is not arranged over the rib of housing middle.

② Twist the relay cable two turns clockwise.

Labels: relay cable, [blue], SUB R board, "B" mark, rib of housing middle



# WH-1000XM5

## 2-9. SUB R BOARD-2 (R-ch)

• Continued on 2-10 (page 14).

**flexible flat cable (20 core) setting**

press inward

flexible flat SUB R board cable (20 core)

**NG**  
Flexible flat cable (20 core) is not pressed inward.

flexible flat SUB R board cable (20 core)

**1** Draw out the flexible flat cable (20 core) from the connector (CN2102) on the SUB R board.

**R 3 MIC module setting**

press inward

R 3 MIC module SUB R board module

**NG**  
R 3 MIC module is not pressed inward.

R 3 MIC SUB R board module

**2** Draw out the R 3 MIC module from the connector (CN2306) on the SUB R board.

**• How to install the R 3 MIC module**  
Insert the R 3 MIC module straight into the interior.  
There is a possibility that using this unit without the connector correctly installed will damage it.

**OK**  
Insert straight into the interior.

R 3 MIC module  
white line  
connector

**NG**  
Insert only part way.

R 3 MIC module  
white line  
connector

**• How to install the flexible flat cable (20 core)**  
Insert the flexible flat cable (20 core) straight into the interior.  
There is a possibility that using this unit without the connector correctly installed will damage it.

**OK**  
Insert straight into the interior.

flexible flat cable (20 core)  
colored line  
connector

**NG**  
Insert at a slant.

flexible flat cable (20 core)  
colored line  
connector



**NG**  
Insert only part way.

flexible flat cable (20 core)  
colored line  
connector

# WH-1000XM5

## 2-10. SUB R BOARD-3 (R-ch)

• Continued on 2-11 (page 15).




### • How to install the R 1 MIC module

Insert the R 1 MIC module straight into the interior. There is a possibility that using this unit without the connector correctly installed will damage it.


**OK**

Insert straight into the interior.



**NG**

Insert only part way.




① Draw out the R 1 MIC module from the connector (CN2305) on the SUB R board.

### • MMD R wire setting




Attach in order from ① to ④.

< Fig. F >



# WH-1000XM5


## 2-11. SUB R BOARD-4 (R-ch)



# WH-1000XM5

## 2-12. USB R BOARD-1 (R-ch)


• Continued on 2-13 (page 17).






## WH-1000XM5

## 2-13. USB R BOARD-2 (R-ch)




# WH-1000XM5

## 2-14. HOUSING REAR L SUB ASSY (L-ch)



**Note 1:** When the connector of the lithium-ion rechargeable battery on the R-ch side is connected, it is energization state. Be careful not to touch the internal board, etc.



**Note 2:** When installing the housing rear L sub assy, align the concave block and convex block.

**• Checking after installing the housing rear L sub assy**

**OK**

There is no gap, housing rear L sub assy is completely installed to the plate front block (L-ch).

housing rear L sub assy

plate front block (L-ch)


**NG**

There is gap, housing rear L sub assy is not completely installed to the plate front block (L-ch).

gap

housing rear L sub assy







plate front block (L-ch)



# WH-1000XM5


## 2-15. JACK L BOARD-1 (L-ch)

• Continued on 2-16 (page 20).




## WH-1000XM5


## 2-16. JACK L BOARD-2 (L-ch)



- 3 Draw out the L4 MIC module from the slit of the holder bushing L. (See Fig. L)
- Note 2:** Be careful not to damage the L4 MIC module when pulling it out.




- 2 Draw out the flexible flat cable (20 core) from the slit of the holder bushing L. (See Fig. K)
- Note 1:** Be careful not to damage the flexible flat cable (20 core) when pulling it out.



## • Holder bushing L setting

&lt; Fig. J &gt;


When installing the holder bushing L, align the two holes in the holder bushing L and two bosses in the plate front L, firmly press these portions the holder bushing L to the plate front L.



## • Flexible flat cable (20 core) setting

&lt; Fig. K &gt;


When inserting the flexible flat cable (20 core) to the slit of the holder bushing L, align the black line on the flexible flat cable (20 core) as shown in the figure below.



## • L4 MIC module setting

&lt; Fig. L &gt;




When inserting the L4 MIC module to the slit of the holder bushing L, align the convex block of the L4 MIC module with the position shown in the figure below.



# WH-1000XM5

## 2-17. HEADBAND ASSY-1 (RELAY CABLE: L-ch)


• Continued on 2-18 (page 22).



# WH-1000XM5

## 2-18. HEADBAND ASSY-2 (RELAY CABLE: R-ch)

• Continued on 2-19 (page 23).



**• Relay cable setting**  
Attach in order from ① to ⑥.

① Arrange the wire [blue] of relay cable on the "B" mark side.


② Twist the relay cable two turns clockwise.

**< Fig. D >**  
③ Insert the connector vertically. (The [blue] wire is "B" mark side)

**< Fig. E >**  
④ Arrange the relay cable inside the rib. ⑤ Insert the relay cable inside the hook.

⑥ Check that the relay cable is not arranged over the rib of housing middle.

Labels: relay cable, [blue], SUB R board, "B" mark, rib of housing middle



# WH-1000XM5

## 2-19. HEADBAND ASSY-3 (CONNECTOR: R-ch)

• Continued on 2-20 (page 24).

**flexible flat cable (20 core) setting**

press inward

flexible flat SUB R board cable (20 core)

**NG**  
Flexible flat cable (20 core) is not pressed inward.

flexible flat SUB R board cable (20 core)

**1** Draw out the flexible flat cable (20 core) from the connector (CN2102) on the SUB R board.

**R 3 MIC module setting**

press inward

R 3 MIC module SUB R board

**NG**  
R 3 MIC module is not pressed inward.

R 3 MIC SUB R board module

**2** Draw out the R 3 MIC module from the connector (CN2306) on the SUB R board.

**• How to install the R 3 MIC module**  
Insert the R 3 MIC module straight into the interior.  
There is a possibility that using this unit without the connector correctly installed will damage it.

**OK**  
Insert straight into the interior.

R 3 MIC module  
white line  
connector

**NG**  
Insert only part way.

R 3 MIC module  
white line  
connector

**• How to install the flexible flat cable (20 core)**  
Insert the flexible flat cable (20 core) straight into the interior.  
There is a possibility that using this unit without the connector correctly installed will damage it.

**OK**  
Insert straight into the interior.

flexible flat cable (20 core)  
colored line  
connector

**NG**  
Insert at a slant.

flexible flat cable (20 core)  
colored line  
connector


**NG**  
Insert only part way.

flexible flat cable (20 core)  
colored line  
connector

# WH-1000XM5

## 2-20. HEADBAND ASSY-4 (SCREW and MMD R WIRE: R-ch)


• Continued on 2-21 (page 25).





### • How to install the R 1 MIC module

Insert the R 1 MIC module straight into the interior.  
There is a possibility that using this unit without the connector correctly installed will damage it.

**OK**  
Insert straight into the interior.




**NG**  
Insert only part way.



### • MMD R wire setting

Attach in order from ① to ④.

< Fig. F >






# WH-1000XM5

## 2-21. HEADBAND ASSY-5 (SUB R BOARD: R-ch)

• Continued on 2-22 (page 26).



# WH-1000XM5

## 2-22. HEADBAND ASSY-6 (CUSHION HOUSING: L/R-ch)

• Continued on 2-23 (page 27).

**Note 1:** The left and right cushion housing can be removed using the same procedure. This explanation uses illustrations from the left channel side.


**Note 2:** Be sure to cleanly peel off all double-sided tape remaining on the plate front block.

**4 cushion housing (See Fig. O)**

**2** Insert a knife etc. under the cushion housing and slide it in the direction of the arrow to peel off the cushion housing.

**1** Insert a thin knife etc. into the space between the cushion housing and the plate front block, and carefully peel off the cushion housing from the plate front block.

**3** Peel off the cushion housing in the direction of the arrow.



### • How to install the cushion housing

When installing the cushion housing, align the convex block of the cushion housing and the convex block of the plate front block.

Also after installing, press firmly the cushion housing to the plate front block.

**Note 3:** The left and right cushion housing can be installed using the same procedure.

This explanation uses illustrations from the left channel side.


< Fig. O >

**NG**

The convex block of the cushion housing is not inserted into the convex block of the plate front block.


# WH-1000XM5

## 2-23. HEADBAND ASSY-7



③ Draw the relay cable connector out from the hole of holder hanger.  
**Note:** Bend the connector as shown in the figure and detach it from the hole of the holder hanger carefully so that the connector does not get damaged or get detached from the relay cable connector.

③ Draw the relay cable connector out from the hole of holder hanger.  
**Note:** Bend the connector as shown in the figure and detach it from the hole of the holder hanger carefully so that the connector does not get damaged or get detached from the relay cable connector.




# WH-1000XM5

## SECTION 3 EXPLODED VIEWS

**Note:**

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Color Indication of Appearance Parts Example:  
 KNOB, BALANCE (WHITE) . . . (RED)  
 ↑                    ↑  
 Parts Color    Cabinet's Color


### 3-1. EARPAD SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	503763311	EARPAD (L) BK (for L-ch) (with Model number label)	(BLACK) (for Black)	2	503386821	EARPAD (R) (for R-ch) (BLACK) (for Black)	
1	503763411	EARPAD (L) S (for L-ch) (with Model number label)	(SILVER) (for Platinum Silver)	2	503386831	EARPAD (R) (for R-ch) (SILVER) (for Platinum Silver)	
1	504134511	EARPAD (L) L (for L-ch) (with Model number label)	(BLUE) (for Midnight Blue)	2	503380551	EARPAD (R) (for R-ch) (BLUE) (for Midnight Blue)	
1	506205911	EARPAD (L) P (for L-ch) (with Model number label)	(PINK) (for Smoky Pink)	2	503380561	EARPAD (R) (for R-ch) (PINK) (for Smoky Pink)	

# WH-1000XM5


## 3-2. HOUSING SECTION (R-ch)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	503377601	SCREEN R (for R-ch)		TPAD1	A5049093A	HOUSING REAR R SUB ASSY L, SV (for R-ch)	
52	503214631	SCREW, TAPPING, P2, TOTSUPURA (L = 8.0 mm)	(Silver)			(Including Resistor BRC, TPAD R flexible board, Sheet busteraid) (for Midnight Blue)	
TPAD1	A5045611A	HOUSING REAR R SUB ASSY B, SV (for R-ch)		TPAD1	A5073263A	HOUSING REAR R SUB ASSY P, SV (for R-ch)	
		(Including Resistor BRC, TPAD R flexible board, Sheet busteraid) (for Black)				(Including Resistor BRC, TPAD R flexible board, Sheet busteraid) (for Smoky Pink)	
TPAD1	A5045612A	HOUSING REAR R SUB ASSY S, SV (for R-ch)					
		(Including Resistor BRC, TPAD R flexible board, Sheet busteraid) (for Platinum Silver)					

# WH-1000XM5

## 3-3. SUB R BOARD SECTION




**Note:** When peeling off the adhesive cable battery (Ref. No. 105), be careful not to damage the coating of lithium-ion rechargeable battery.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	503214621	SCREW, TAPPING, P2, TOTSUPURA (L = 5.0 mm)	(Black)	104	503635111	CUSHION HEAT CONDUCTION LARGE	
103	503531811	CUSHION HEAT CONDUCTION SMALL		105	503828301	ADHESIVE CABLE BATTERY (See Note)	

# WH-1000XM5


## 3-4. HOUSING SECTION (L-ch)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	503376301	SCREEN L (for L-ch)		153	A5049092A	HOUSING REAR L SUB ASSY L, SV (for L-ch) (Including Resistor BRC) (for Midnight Blue)	
152	503214631	SCREW, TAPPING, P2, TOTSUPURA (L = 8.0 mm)	(Silver)	153	A5073262A	HOUSING REAR L SUB ASSY P, SV (for L-ch) (Including Resistor BRC) (for Smoky Pink)	
153	A5045609A	HOUSING REAR L SUB ASSY B, SV (for L-ch) (Including Resistor BRC) (for Black)					
153	A5045610A	HOUSING REAR L SUB ASSY S, SV (for L-ch) (Including Resistor BRC) (for Platinum Silver)					

# WH-1000XM5

## 3-5. JACK L BOARD, USB R BOARD, HEADBAND ASSY SECTION



**Note 1:** The USB R board is bundled in the complete JACK L board (Ref. No. 252) for repair board, but it is not necessary to replace the JACK L board and the USB R board at the same time. Use only the board that needs replacement.

**Note 2:** The JACK L board is bundled in the complete USB R board (Ref. No. 254) for repair board, but it is not necessary to replace the USB R board and the JACK L board at the same time. Use only the board that needs replacement.

Ref. No.	Part No.	Description	Remark
251	503214621	SCREW, TAPPING, P2, TOTSUPURA (L = 5.0 mm) (Black)	
252	A5066088A	JACK L BOARD, COMPLETE (Including USB R board, Flexible flat cable (20 core), Cushion FFC) (See Note 1)	
253	503375701	CUSHION HOUSING	
254	A5066088A	USB R BOARD, COMPLETE (Including JACK L board, Flexible flat cable (20 core), Cushion FFC) (See Note 2)	

Ref. No.	Part No.	Description	Remark
HB1	A5072931A	HEADBAND ASSY B SV (for Black)	
HB1	A5072932A	HEADBAND ASSY S SV (for Platinum Silver)	
HB1	A5072933A	HEADBAND ASSY L SV (for Midnight Blue)	
HB1	A5073265A	HEADBAND ASSY P, SV (for Smoky Pink)	



**WH-1000XM5****SECTION 4  
ACCESSORIES**

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
	503539543	REFERENCE GUIDE (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH, SWEDISH, ITALIAN, PORTUGUESE, DANISH, FINNISH, NORWEGIAN)	
	503539553	REFERENCE GUIDE (POLISH, GREEK, CZECH, HUNGARIAN, BULGARIAN, SLOVAK, SLOVENIAN, CROATIAN, ROMANIAN, SERBIAN)	
501	101614711	USB TYPE-C TO A CABLE (USB Type-C® cable (USB-A to USB-C®) (approx. 20 cm))	
502	100349432	CABLE (WITH PLUG) B (Headphone cable (approx. 1.2 m))	
503	503601321	CASE CARRYING K (BLUE) (for Midnight Blue)	
503	503601401	CASE CARRYING T (BLACK) (for Black)	
503	503601411	CASE CARRYING T (LIGHT GRAY) (for Platinum Silver)	
503	503601421	CASE CARRYING T (PINK) (for Smoky Pink)	

