

SRS-XB13

SERVICE MANUAL

DISCLAIMER: USE AT OWN RISK.

SONY AND ITS AFFILIATES ARE NOT LIABLE FOR ANY DAMAGE OR INJURY CAUSED TO ANY DIGITAL ELECTRONIC EQUIPMENT, PERSON, OR PROPERTY, WHICH OCCURS DUE TO USE OF THE TOOLS, PARTS, DOCUMENTATION, OR OTHER MATERIALS HEREIN PROVIDED, WHETHER FOR REPAIR, DIAGNOSIS, MAINTENANCE, MODIFICATION, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO: ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES; ANY LOSS OF DATA, PRIVACY OR PROFITS; OR ANY INABILITY TO USE, OR REDUCED FUNCTIONALITY OF, THE DIGITAL ELECTRONIC EQUIPMENT. PLEASE READ ALL INSTRUCTIONS IN THIS MANUAL BEFORE PROCEEDING. PLEASE FOLLOW ALL STEPS IN THE ORDER IN WHICH THEY ARE DESCRIBED. IF YOU DO NOT HAVE ALL TOOLS AND PARTS AVAILABLE TO YOU, OR ARE NOT COMFORTABLE PERFORMING THE REPAIRS DESCRIBED HEREIN, DO NOT PROCEED. FAILURE TO FOLLOW THESE INSTRUCTIONS, OR USE THE PROPER TOOLS AND PARTS, MAY DAMAGE YOUR PRODUCT, LEAD TO PERSONAL INJURY OR CAUSE PROPERTY DAMAGE.

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

SRS-XB13

SERVICE MANUAL

US Model


- **Color variations**

(B) Black, (C) Taupe, (L) Light Blue, (LI) Powder Blue, (P) Coral Pink

- The service policy of this model is Product Exchange.
The following parts are available for service parts of this model.

PARTS LIST


Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	502546611	OPERATING INSTRUCTIONS		1	930100849	CORD, CONNECTION	
	502546711	REFERENCE GUIDE (ENGLISH, FRENCH, SPANISH)				(USB Type-C cable (USB-A to USB-C))	
				2	502789201	STRAP (for Black)	
				2	502789211	STRAP (for Light Blue)	
				2	502789221	STRAP (for Taupe)	
				2	502789231	STRAP (for Coral Pink)	
				2	502789251	STRAP (for Powder Blue)	



MODEL IDENTIFICATION

When identifying the destination, refer to the model number notation on the bottom side.

Note 1: The contents of the model number notation might be changed in the midway of production.



Note 2: This model number notation indicates that it is SRS-XB13 for US.
If the model number notation is other than this, it is SRS-XB13 with a destination other than US.

WIRELESS SPEAKER