

# SRS-XB23

## SERVICE MANUAL

**DISCLAIMER: USE AT OWN RISK.**

SONY AND ITS AFFILIATES ARE NOT LIABLE FOR ANY DAMAGE OR INJURY CAUSED TO ANY DIGITAL ELECTRONIC EQUIPMENT, PERSON, OR PROPERTY, WHICH OCCURS DUE TO USE OF THE TOOLS, PARTS, DOCUMENTATION, OR OTHER MATERIALS HEREIN PROVIDED, WHETHER FOR REPAIR, DIAGNOSIS, MAINTENANCE, MODIFICATION, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO: ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES; ANY LOSS OF DATA, PRIVACY OR PROFITS; OR ANY INABILITY TO USE, OR REDUCED FUNCTIONALITY OF, THE DIGITAL ELECTRONIC EQUIPMENT. PLEASE READ ALL INSTRUCTIONS IN THIS MANUAL BEFORE PROCEEDING. PLEASE FOLLOW ALL STEPS IN THE ORDER IN WHICH THEY ARE DESCRIBED. IF YOU DO NOT HAVE ALL TOOLS AND PARTS AVAILABLE TO YOU, OR ARE NOT COMFORTABLE PERFORMING THE REPAIRS DESCRIBED HEREIN, DO NOT PROCEED. FAILURE TO FOLLOW THESE INSTRUCTIONS, OR USE THE PROPER TOOLS AND PARTS, MAY DAMAGE YOUR PRODUCT, LEAD TO PERSONAL INJURY OR CAUSE PROPERTY DAMAGE.

**CAUTION**

Danger of explosion if battery is incorrectly replaced.  
Replace only with the same or equivalent type.

# SRS-XB23

## SERVICE MANUAL

US Model


- **Color variations**

(B) Black, (C) Taupe, (L) Light Blue, (LI) Powder Blue, (P) Coral Pink

- The service policy of this model is Product Exchange.  
The following parts are available for service parts of this model.

### PARTS LIST

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	501296111	OPERATING INSTRUCTIONS		1	501296301	STRAP WITH HOOK (Strap) (for Black)	
	501296211	REFERENCE GUIDE 1 (Reference Guide) (ENGLISH, FRENCH, SPANISH)		1	501296311	STRAP WITH HOOK (Strap) (for Light Blue)	
				1	501296321	STRAP WITH HOOK (Strap) (for Coral Red)	
				1	501296331	STRAP WITH HOOK (Strap) (for Taupe)	
				1	501296341	STRAP WITH HOOK (Strap) (for Olive Green)	
				2	930100334	CORD, CONNECTION (50) (USB Type-C® cable (USB-A to USB-C® / Max. 1.5 A))	




### MODEL IDENTIFICATION

When identifying the destination, refer to the model number notation of the outside the cap or inside the cap.

**Note 1:** The contents of model number notation might be changed in the midway of production.

**Note 2:** There are two types of model number notation depending on the country of origin.



**Note 4:** The made in Vietnam type has labels affixed to the following locations.

label  
(Made in Vietnam)



#### - Outside the cap -

See Note 2


MODEL No. SRS-XB23  
WIRELESS SPEAKER  
Fabriqué en Chine  
CAN ICES-3 B/NMB-3 B  
Contains /Contient IC: 23011-BMS001  
Contains FCC ID: 2AMX3BMS001

See Note 2, 4


MODEL No. SRS-XB23  
WIRELESS SPEAKER  
CAN ICES-3 B/NMB-3 B  
Contains /Contient IC: 23011-BMS001  
Contains FCC ID: 2AMX3BMS001

#### - Inside the cap -

See Note 2

INPUT:DC 5V  $\equiv$  1.5A   
SONY® AV EQUIPMENT E192039

See Note 2, 4

INPUT:DC 5V  $\equiv$  1.5A   
SONY® AV EQUIPMENT E192039

**Note 3:** This model number notation indicates that it is SRS-XB23 for US.  
If the model number notation is other than this, it is SRS-XB23 with a destination other than US.

## WIRELESS SPEAKER