

SERVICE MANUAL

DISCLAIMER: USE AT OWN RISK.

SONY AND ITS AFFILIATES ARE NOT LIABLE FOR ANY DAMAGE OR INJURY CAUSED TO ANY DIGITAL ELECTRONIC EQUIPMENT, PERSON, OR PROPERTY, WHICH OCCURS DUE TO USE OF THE TOOLS, PARTS, DOCUMENTATION, OR OTHER MATERIALS HEREIN PROVIDED, WHETHER FOR REPAIR, DIAGNOSIS, MAINTENANCE, MODIFICATION, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO: ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES; ANY LOSS OF DATA, PRIVACY OR PROFITS; OR ANY INABILITY TO USE, OR REDUCED FUNCTIONALITY OF, THE DIGITAL ELECTRONIC EQUIPMENT. PLEASE READ ALL INSTRUCTIONS IN THIS MANUAL BEFORE PROCEEDING. PLEASE FOLLOW ALL STEPS IN THE ORDER IN WHICH THEY ARE DESCRIBED. IF YOU DO NOT HAVE ALL TOOLS AND PARTS AVAILABLE TO YOU, OR ARE NOT COMFORTABLE PERFORMING THE REPAIRS DESCRIBED HEREIN, DO NOT PROCEED. FAILURE TO FOLLOW THESE INSTRUCTIONS, OR USE THE PROPER TOOLS AND PARTS, MAY DAMAGE YOUR PRODUCT, LEAD TO PERSONAL INJURY OR CAUSE PROPERTY DAMAGE.

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

LinkBuds

WF-L900/YY2953

SERVICE MANUAL


US Model

- This unit has three types of names for communication name (LinkBuds), model name (WF-L900), and model (YY2953). In addition, there are no unique model names for the left and right headset, charging case.
- LinkBuds/WF-L900/YY2953 is composed of Headset (Left and Right) and charging case.
- Color variations**
(H) Gray, (W) White

- The service policy of this model is Product Exchange.
The following parts are available for service parts of this model.

PARTS LIST

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	503111711	REFERENCE GUIDE (ENGLISH, FRENCH, SPANISH)		4	502856801	SUPPORTER (M) (Fitting supporter: size M) (1 piece) (for Gray)	
1	101614711	USB TYPE-C TO ACABLE (USB Type-C® cable (USB-A to USB-C®) (approx. 20 cm))		4	502856811	SUPPORTER (M) (Fitting supporter: size M) (1 piece) (for White)	
2	502856701	SUPPORTER (XS) (Fitting supporter: size XS) (1 piece) (for Gray)		5	503750601	SUPPORTER (L) (Fitting supporter: size L) (1 piece) (for Gray)	
2	502856711	SUPPORTER (XS) (Fitting supporter: size XS) (1 piece) (for White)		5	503750611	SUPPORTER (L) (Fitting supporter: size L) (1 piece) (for White)	
3	503750501	SUPPORTER (S) (Fitting supporter: size S) (1 piece) (for Gray)		6	502856901	SUPPORTER (XL) (Fitting supporter: size XL) (1 piece) (for Gray)	
3	503750511	SUPPORTER (S) (Fitting supporter: size S) (1 piece) (for White)		6	502856911	SUPPORTER (XL) (Fitting supporter: size XL) (1 piece) (for White)	




MODEL IDENTIFICATION

When identifying the destination, refer to the model number notation on the bottom of the charging case.

Note 1: The contents of the model number notation might be changed in the midway of production.

Note 2: It cannot identify the destination by referring to the left and right headset.



Note 3: This model number notation indicates that it is LinkBuds/WF-L900/YY2953 for US.
If the model number notation is other than this, it is LinkBuds/WF-L900/YY2953 with a destination other than US.


CHECK OF MODEL NAME, MODEL AND SERIAL NUMBER

When checking the model name or serial number, refer to the model number notation on the bottom of the charging case.

Note 1: Serial numbers are not written on the left and right headset.

Note 2: The model name (WF-L900) and model (YY2953) are shown on the charging case. Only the model (YY2953) is shown in the left and right headset. There is no display of the communication name.

Note 3: The contents of the model number notation might be changed in the midway of production.



WIRELESS STEREO HEADSET