

SERVICE MANUAL

DISCLAIMER: USE AT OWN RISK.

SONY AND ITS AFFILIATES ARE NOT LIABLE FOR ANY DAMAGE OR INJURY CAUSED TO ANY DIGITAL ELECTRONIC EQUIPMENT, PERSON, OR PROPERTY, WHICH OCCURS DUE TO USE OF THE TOOLS, PARTS, DOCUMENTATION, OR OTHER MATERIALS HEREIN PROVIDED, WHETHER FOR REPAIR, DIAGNOSIS, MAINTENANCE, MODIFICATION, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO: ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES; ANY LOSS OF DATA, PRIVACY OR PROFITS; OR ANY INABILITY TO USE, OR REDUCED FUNCTIONALITY OF, THE DIGITAL ELECTRONIC EQUIPMENT. PLEASE READ ALL INSTRUCTIONS IN THIS MANUAL BEFORE PROCEEDING. PLEASE FOLLOW ALL STEPS IN THE ORDER IN WHICH THEY ARE DESCRIBED. IF YOU DO NOT HAVE ALL TOOLS AND PARTS AVAILABLE TO YOU, OR ARE NOT COMFORTABLE PERFORMING THE REPAIRS DESCRIBED HEREIN, DO NOT PROCEED. FAILURE TO FOLLOW THESE INSTRUCTIONS, OR USE THE PROPER TOOLS AND PARTS, MAY DAMAGE YOUR PRODUCT, LEAD TO PERSONAL INJURY OR CAUSE PROPERTY DAMAGE.

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.

WH-CH520

YY2958

SERVICE MANUAL


US Model

- This unit has two types of names for model name (WH-CH520) and model (YY2958).
- **Color variations**
(B) Black, (C) Beige, (L) Blue, (W) White

- The service policy of this model is Product Exchange.
The following parts are available for service parts of this model.

PARTS LIST

| Ref. No. | Part No. | Description | Remark | Ref. No. | Part No. | Description | Remark |
|----------|-----------|---|--------|----------|-----------|---|--------|
| | 504417711 | REFERENCE GUIDE (ENGLISH, FRENCH, SPANISH) | | 1 | 930101697 | CABLE, USB TYPE-C(USB Type-C® cable (USB-A to USB-C®) (approx. 20 cm)) | |
| | | | | 2 | 930101693 | EARPAD (B) (1 piece) (for Black) | |
| | | | | 2 | 930101694 | EARPAD (L) (1 piece) (for Blue) | |
| | | | | 2 | 930101695 | EARPAD (W) (1 piece) (for White) | |
| | | | | 2 | 930101696 | EARPAD (C) (1 piece) (for Beige) | |



MODEL IDENTIFICATION

When identifying the destination, refer to the model number label on the inside of the left side earpads.

Note 1: The contents of model number label might be changed in the midway of production.



Note 2: This model number label indicates that it is WH-CH520/YY2958 for US. If the model number label is other than this, it is WH-CH520/YY2958 with a destination other than US.

WIRELESS STEREO HEADSET