

## SERVICE MANUAL

**DISCLAIMER: USE AT OWN RISK.**

SONY AND ITS AFFILIATES ARE NOT LIABLE FOR ANY DAMAGE OR INJURY CAUSED TO ANY DIGITAL ELECTRONIC EQUIPMENT, PERSON, OR PROPERTY, WHICH OCCURS DUE TO USE OF THE TOOLS, PARTS, DOCUMENTATION, OR OTHER MATERIALS HEREIN PROVIDED, WHETHER FOR REPAIR, DIAGNOSIS, MAINTENANCE, MODIFICATION, OR OTHERWISE, INCLUDING BUT NOT LIMITED TO: ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES; ANY LOSS OF DATA, PRIVACY OR PROFITS; OR ANY INABILITY TO USE, OR REDUCED FUNCTIONALITY OF, THE DIGITAL ELECTRONIC EQUIPMENT. PLEASE READ ALL INSTRUCTIONS IN THIS MANUAL BEFORE PROCEEDING. PLEASE FOLLOW ALL STEPS IN THE ORDER IN WHICH THEY ARE DESCRIBED. IF YOU DO NOT HAVE ALL TOOLS AND PARTS AVAILABLE TO YOU, OR ARE NOT COMFORTABLE PERFORMING THE REPAIRS DESCRIBED HEREIN, DO NOT PROCEED. FAILURE TO FOLLOW THESE INSTRUCTIONS, OR USE THE PROPER TOOLS AND PARTS, MAY DAMAGE YOUR PRODUCT, LEAD TO PERSONAL INJURY OR CAUSE PROPERTY DAMAGE.

**CAUTION**

Danger of explosion if battery is incorrectly replaced.  
Replace only with the same or equivalent type.

# SERVICE MANUAL


US Model

- This unit has two types of names for model name (WI-C100) and model (YY2957).
- Color variations**  
(B) Black, (C) Taupe, (L) Blue, (W) White

- The service policy of this model is Product Exchange.  
The following parts are available for service parts of this model.

## PARTS LIST


Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	503667911	REFERENCE GUIDE (ENGLISH, FRENCH, SPANISH)		2	457565532	PIECE (M), EAR (Hybrid silicone rubber earbud tip) (size M) (1 piece) (3 line: TRANSPARENT NAVY) (for Blue)	
1	327525701	PIECE (SS), EAR (Hybrid silicone rubber earbud tip) (size SS) (1 piece) (Outside: BLACK/Inside: RED) (for Black)		2	457565571	PIECE (M), EAR (Hybrid silicone rubber earbud tip) (size M) (1 piece) (3 line: BEIGE) (for Taupe)	
1	419635001	PIECE (SS), EAR (Hybrid silicone rubber earbud tip) (size SS) (1 piece) (1 line: TRANSPARENT MILKEY) (for White)		3	327525801	PIECE (LL), EAR (Hybrid silicone rubber earbud tip) (size LL) (1 piece) (Outside: BLACK/Inside: PURPLE) (for Black)	
1	457565832	PIECE (SS), EAR (Hybrid silicone rubber earbud tip) (size SS) (1 piece) (1 line: TRANSPARENT NAVY) (for Blue)		3	473939211	PIECE (LL), EAR (Hybrid silicone rubber earbud tip) (size LL) (1 piece) (5 lines: MILKEY WHITE) (for White)	
1	457565871	PIECE (SS), EAR (Hybrid silicone rubber earbud tip) (size SS) (1 piece) (1 line: BEIGE) (for Taupe)		3	473939241	PIECE (LL), EAR (Hybrid silicone rubber earbud tip) (size LL) (1 piece) (5 line: BEIGE) (for Taupe)	
2	327525401	PIECE (M), EAR (Hybrid silicone rubber earbud tip) (size M) (1 piece) (Outside: BLACK/Inside: GREEN) (for Black)		3	503025531	PIECE (LL), EAR (Hybrid silicone rubber earbud tip) (size LL) (1 piece) (5 line: TRANSPARENT NAVY) (for Blue)	
2	419634801	PIECE (M), EAR (Hybrid silicone rubber earbud tip) (size M) (1 piece) (3 lines: TRANSPARENT MILKEY) (for White)					




## MODEL IDENTIFICATION

When identifying the destination, model name, model and serial number, refer to the model number notation on the inside of the right channel.

**Note 1:** The contents of model number notation might be changed in the midway of production.



**Note 2:** This model number notation indicates that it is WI-C100/YY2957 for US.  
If the model number notation is other than this, it is WI-C100/YY2957 with a destination other than US.



# WIRELESS STEREO HEADSET