




12-1. Control Panel & Plate Assembly




12-2. Cabinet & Door Assembly





12-3-2. Drum & Motor Assembly: Gas type



CAUTION : Before replacing any part of these components
Read carefully the safety precautions in this manual

■ **NOTE** : S(Safety Parts), AL(Alternative parts)

LOC	DESC	DLE8377WM	DLE8377NW	QTY
*001	MANUAL ASSEMBLY,OWNERS	3829EL3009B	3829EL3009B	1
*002	BOX,CARTON	3890EZ3613A	3890EZ3613A	1
*004	MANUAL,SERVICE	3828EL3005D	3828EL3005D	0
A110	PANEL ASSEMBLY,CONTROL	3721EL0009A	3721EL0009C	1
A120	PWB(PCB) ASSEMBLY,DISPLAY	6871EL1011A	6871EL1011A	1
A130	PWB(PCB) ASSEMBLY,MAIN	6871EL1013C	6871EL1013C	1
A140	KNOB ASSEMBLY	4941ER3002A	4941ER3002A	1
A210	TOP PLATE ASSEMBLY	3457ER1006D	3457ER1006X	1
A300	BRACKET,HINGE	4810EL3006A	4810EL3006A	1
A305	BRACKET,HINGE	4810EL3006B	4810EL3006B	1
A310	COVER ASSEMBLY,CABINET	3551EL0009A	3551EL0009B	1
A320	LATCH ASSEMBLY	4027EL1001A	4027EL1001A	1
A330	SWITCH ASSEMBLY,SAFETY	6601EL3001A	6601EL3001A	1
A390	FRAME ASSEMBLY	3211EL1004A	3211EL1004A	1
A400	DOOR ASSEMBLY	3581EL0004A	3581EL0004A	1
A410	LATCH,HOOK	4026EL3007A	4026EL3007A	1
A420	DOOR FRAME,OUTER	3212EL1015A	3212EL1015A	1
A430	HINGE	4774EL2001A	4774EL2001A	1
A450	DOOR FRAME,INNER	3212EL1005B	3212EL1005B	1
A460	GASKET	4986EL2004A	4986EL2004A	1
A500	CABINET ASSEMBLY	3091EL0003M	3091EL0003P	1
A510	CAP,DRIER	5006EL3001D	5006EL3001G	2
A520	BRACKET,BASE	4810EL3001A	4810EL3001A	2
A540	LEG	4778EL3001A	4778EL3001A	4
A560	COVER,GUIDE	3550EL3007A	3550EL3007A	1
A570	COVER,SAFETY	3550EL3002A	3550EL3002A	1
A600	HARNESS,PWB	6877EL1019B	6877EL1019B	1
A700	RACK	3750EL1001B	3750EL1001B	1
A800	SERVICE PARTS	383EEL9001B	383EEL9001B	0
F110	HEATER ASSEMBLY	5301EL1001G	5301EL1001G	1
F120	BRACKET,HEATER	4810EL1007A	4810EL1007A	1
F130	THERMOSTAT ASSEMBLY	6931EL3003D	6931EL3003D	1
F200	DUCT ASSEMBLY	5209EL1001C	5209EL1001C	1
K100	TUB ASSEMBLY,DRUM	3045EL1002E	3045EL1002E	1
K120	LIFTER	4432EL1002B	4432EL1002B	3
K130	BELT,POLY-V	4400EL2001A	4400EL2001A	1
K140	SEAL	4036EL3001A	4036EL3001A	2
K210	TUB,DRUM[FRONT]	3044EL1001A	3044EL1001A	1
K221	LAMP ASSEMBLY	6913EL3002C	6913EL3002C	1
K222	LAMP ASSEMBLY	6913EL3001A	6913EL3001A	1
K230	COVER,LAMP	3550EL2001A	3550EL2001A	1
K240	DUCT ASSEMBLY	5209EL1002A	5209EL1002A	1
K250	ROLLER ASSEMBLY	4581EL2002A	4581EL2002A	2
K250	ROLLER ASSEMBLY	4581EL2002A	4581EL2002A	2
K251	ROLLER ASSEMBLY	4581EL3001A	4581EL3001A	1
K251	ROLLER ASSEMBLY	4581EL3001A	4581EL3001A	1
K310	FILTER ASSEMBLY,LINT	5231EL1003B	5231EL1003B	1
K320	COVER,GUIDE	3550EL1006B	3550EL1006B	1
K330	GUIDE,FILTER	4974EL1003B	4974EL1003B	1
K340	SENSOR	6500EL3001A	6500EL3001A	2
K350	CONNECTOR ASSEMBLY	6631EL3003B	6631EL3003B	1
K360	HOLDER	4930EL2004B	4930EL2004B	1
K400	TUB,DRUM[BACK]	3044EL0002B	3044EL0002B	1
K510	BLOWER ASSEMBLY	5835EL1002A	5835EL1002A	1
K520	HOUSING ASSEMBLY (MECH),BLOWER	3661EL1001E	3661EL1001E	1
K530	DUCT ASSEMBLY	5209EL1006A	5209EL1006A	1
K540	GUIDE ASSEMBLY	4975EL3001A	4975EL3001A	1
K550	THERMISTOR ASSEMBLY	6323EL2001E	6323EL2001E	1
K560	THERMOSTAT ASSEMBLY	6931EL3002A	6931EL3002A	1
K610	MOTOR ASSEMBLY,WM	4681EL1002A	4681EL1002A	1
K620	CLAMP	4860EL3001A	4860EL3001A	2
K640	SWITCH,MICRO	3W40025Q	3W40025Q	1
K650	PULLEY ASSEMBLY,MOTOR	4561EL3002A	4561EL3002A	1
K651	PULLEY,IDLE	4560EL3001A	4560EL3001A	1

CAUTION : Before replacing any part of these components
Read carefully the safety precautions in this manual

■ **NOTE** : S(Safety Parts), AL(Alternative parts)

LOC	DESC	DLG8388WM	DLG8388NM	QTY
*001	MANUAL ASSEMBLY,OWNERS	3829EL3009B	3829EL3009B	1
*002	BOX,CARTON	3890EZ3613A	3890EZ3613A	1
*004	MANUAL,SERVICE	3828EL3005D	3828EL3005D	0
A110	PANEL ASSEMBLY,CONTROL	3721EL0009B	3721EL0009D	1
A120	PWB(PCB) ASSEMBLY,DISPLAY	6871EL1011B	6871EL1011B	1
A130	PWB(PCB) ASSEMBLY,MAIN	6871EL1013D	6871EL1013D	1
A140	KNOB ASSEMBLY	4941ER3002A	KNOB ASSEMBLY	1
A210	TOP PLATE ASSEMBLY	3457ER1006D	3457ER1006X	1
A300	BRACKET,HINGE	4810EL3006A	4810EL3006A	1
A305	BRACKET,HINGE	4810EL3006B	4810EL3006B	1
A310	COVER ASSEMBLY,CABINET	3551EL0009A	3551EL0009B	1
A320	LATCH ASSEMBLY	4027EL1001A	4027EL1001A	1
A330	SWITCH ASSEMBLY,SAFETY	6601EL3001A	6601EL3001A	1
A390	FRAME ASSEMBLY	3211EL1004A	3211EL1004A	1
A400	DOOR ASSEMBLY	3581EL0004A	3581EL0004A	1
A410	LATCH,HOOK	4026EL3007A	4026EL3007A	1
A420	DOOR FRAME,OUTER	3212EL1015A	3212EL1015A	1
A430	HINGE	4774EL2001A	4774EL2001A	1
A450	DOOR FRAME,INNER	3212EL1005B	3212EL1005B	1
A460	GASKET	4986EL2004A	4986EL2004A	1
A500	CABINET ASSEMBLY	3091EL0003N	3091EL0003Q	1
A510	CAP,DRIER	5006EL3001D	5006EL3001G	2
A520	BRACKET,BASE	4810EL3001A	4810EL3001A	2
A540	LEG	4778EL3001A	4778EL3001A	4
A550	POWER CORD ASSEMBLY	6411ER1005B	6411ER1005B	1
A600	HARNESS,PWB	6877EL1020B	6877EL1020B	1
A700	RACK	3750EL1001B	3750EL1001B	1
A800	SERVICE PARTS	383EEL9001B	383EEL9001B	0
F200	DUCT ASSEMBLY	5209EL1001D	5209EL1001D	1
K100	TUB ASSEMBLY,DRUM	3045EL1002E	3045EL1002E	1
K120	LIFTER	4432EL1002B	4432EL1002B	3
K130	BELT,POLY-V	4400EL2001A	4400EL2001A	1
K140	SEAL	4036EL3001A	4036EL3001A	2
K210	TUB,DRUM[FRONT]	3044EL1001B	3044EL1001B	1
K221	LAMP ASSEMBLY	6913EL3002C	6913EL3002C	1
K222	LAMP ASSEMBLY	6913EL3001A	6913EL3001A	1
K230	COVER,LAMP	3550EL2001A	3550EL2001A	1
K240	DUCT ASSEMBLY	5209EL1002A	5209EL1002A	1
K250	ROLLER ASSEMBLY	4581EL2002A	4581EL2002A	2
K250	ROLLER ASSEMBLY	4581EL2002A	4581EL2002A	2
K251	ROLLER ASSEMBLY	4581EL3001A	4581EL3001A	1
K251	ROLLER ASSEMBLY	4581EL3001A	4581EL3001A	1
K310	FILTER ASSEMBLY,LINT	5231EL1003B	5231EL1003B	1
K320	COVER,GUIDE	3550EL1006B	3550EL1006B	1
K330	GUIDE,FILTER	4974EL1003B	4974EL1003B	1
K340	SENSOR	6500EL3001A	6500EL3001A	2
K350	CONNECTOR ASSEMBLY	6631EL3003B	6631EL3003B	1
K360	HOLDER	4930EL2004B	4930EL2004B	1
K400	TUB,DRUM[BACK]	3044EL0002B	3044EL0002B	1
K510	BLOWER ASSEMBLY	5835EL1002A	5835EL1002A	1
K520	HOUSING ASSEMBLY (MECH),BLOWER	3661EL1001E	3661EL1001E	1
K530	DUCT ASSEMBLY	5209EL1006A	5209EL1006A	1
K540	GUIDE ASSEMBLY	4975EL3001A	4975EL3001A	1
K550	THERMISTOR ASSEMBLY	6323EL2001E	6323EL2001E	1
K560	THERMOSTAT ASSEMBLY	6931EL3002A	6931EL3002A	1
K610	MOTOR ASSEMBLY,WM	4681EL1002A	4681EL1002A	1
K620	CLAMP	4860EL3001A	4860EL3001A	2
K640	SWITCH,MICRO	3W40025Q	3W40025Q	1
K650	PULLEY ASSEMBLY,MOTOR	4561EL3002A	4561EL3002A	1
K651	PULLEY,IDLE	4560EL3001A	4560EL3001A	1
M110	VALVE ASSEMBLY,GAS	5221EL2002A	5221EL2002A	1
M140	GUIDE,BURNER	4974EL1001A	4974EL1001A	1
M141	BRACKET,BASE	4810EL3002A	4810EL3002A	1
M150	PIPE ASSEMBLY	5201EL3001A	5201EL3001A	1
M160	IGNITER	5318EL3001A	5318EL3001A	1
M170	ORIFICE	4948EL4001B	4948EL4001B	1
M180	CONNECTOR (MECH),PIPE	4932EL4001A	4932EL4001A	1
M181	SEAL	4036EL3002A	4036EL3002A	1
M190	PIPE ASSEMBLY	5201EL2001A	5201EL2001A	1
M210	FUNNEL	3016EL1001A	3016EL1001A	1
M220	THERMOSTAT ASSEMBLY	6931EL3004B	6931EL3004B	1
M230	THERMOSTAT ASSEMBLY	6931EL3003C	6931EL3003C	1
M240	SENSOR ASSEMBLY	6501EL3001A	6501EL3001A	1
M250	SUPPORTER,HOLDER	4980EL3001A	4980EL3001A	1